



2225 N 25th St. Terre Haute, IN 47804 • 812-232-1292 • 1-877-232-1299

Opening your Inground Pool

1. Pump water and clean leaves off of your winter cover.
2. Remove cover.
3. Move filter valve from “Winter” to “Filter” setting, if you have a sand filter.
4. Make sure all drain caps/plugs are returned to the pump and filter.
5. Remove any winter plugs from the skimmer and inlets/outlets- put skimmer basket, pump basket, and directional eyes in, set all ball valves to open.
6. Fill water in pool to the middle of the skimmer.
7. Fill the pump housing with water to prime pump.
8. Turn pump on.
9. Add necessary opening chemicals to your water and let circulate for 24 hours.
10. Take water sample into Sparkle Pools to have your water tested.

Opening Chemicals: You should use one quart of Sparkle Algaecide 30, One quart of Sparkle Stain & Scale, and four gallons of liquid chlorine to open your pool.